

ATARI

LYNX

VIDEO GAME CARD



THE FIDELITY
**ULTIMATE
CHESS
CHALLENGE™**

Telegames, Inc. is unable to guarantee the accuracy of printed material after the date of publication and disclaims liability for changes, errors, or omissions.

Reproduction of this document or of any portion of its contents is not allowed without the specific consent of Telegames, Inc.

Telegames and the Telegames logo are trademarks or registered trademarks of Telegames, Inc. Atari, the Atari logo, ComLynx and Lynx are trademarks or registered trademarks of Atari Corporation.

The Fidelity Ultimate Chess Challenge is a trademark of Telegames, Inc. All rights reserved.



Copyright (c)1991, Telegames, Inc.
Lancaster, Texas 75146
All rights reserved.

LYNX™ Portable

Color Entertainment System

Game Manual

The Fidelity
**Ultimate
Chess
Challenge™**

Table of Contents

Introduction.....	1
Getting Started.....	2
Optional Game Controls.....	4
Playing the Game.....	5
Game Setup.....	5
Game Board	17
Statistics.....	27

Introduction

Congratulations! You have just purchased the most powerful portable chess game available. The Ultimate Chess Challenge is based upon the proven chess-playing technology from the laboratories of Fidelity Electronics - the premier manufacturers of dedicated chess computers and the developers of the only United States Chess Federation Master rated (2325) program. With 17 skill levels, multi-player capability, and selectable 2-D or 3-D modes, you have purchased a product that will challenge even the most serious chess players.

We know that **The Fidelity Ultimate Chess Challenge** will provide you with many hours of enjoyment.

Getting Started

The Fidelity Ultimate Chess Challenge is a multi-level strategy game for one or two players.

1. With your Lynx system off, insert the game card as described in the **Lynx Owner's Manual**.
2. Press **ON**. The Telegames and Fidelity Ultimate Chess Challenge opening screens appear, followed by the Game Setup display. Press **A** or **B** at any time to skip the introductory screens.

Note: To **press** a button, press and release the button quickly. To **hold down** a button, hold the button down for at least one second.

Special Note!

Most Lynx products contain a standard feature that causes the game to turn itself off if left unattended after 5 minutes on batteries, and after 1 hour on the AC power supply.

Since chess is an intricate game, requiring many minutes of deliberation between moves, it was decided that this feature could interfere with advanced levels of play and it was therefore removed.

Please remember, your Lynx will not turn itself off if left unattended!

Optional Game Controls

To enhance play, the following optional game controls allow you to modify the display, and pause and restart the game:

- To **flip** the screen 180 degrees and reverse the controls, press **OPTION 2** and **PAUSE** at the same time.
- To **pause** the game, press **PAUSE**. An animated "PAUSED" message is displayed when pause mode is active. Repeat to resume play.
- To **start** a new game, press **OPTION 1** and **PAUSE**. Restart causes the game to return to the Game Setup display with the most recently selected options still intact. If you exit the Game Setup display without making any changes, you will be starting a game with the same configuration as the previous game.

Playing the Game

The **Fidelity Ultimate Chess Challenge** is divided into three sections, the Game Setup display, the Game Board display, and the Statistics display.

Game Setup

The Game Setup display indicates the current game settings and allows you to modify these settings.

Each game parameter is represented in this display by either a textual representation, or a graphic representation or "icon".

Parameters having either an "on" or "off" setting have that setting indicated by the presence or lack of a European style "no" symbol superimposed over the icon.

To change a parameter, use the joystick to move the pointer over the symbol for the parameter to be changed and press either 'A' or 'B'.

Game parameters include:

Name

Player names appear at the top of the Game Setup display with the silver player's name at left and the gold player's name at right.

To change a player's name, position the pointer over the name to be changed and press either **A** or **B**. This will cause the name entry screen to appear.

The name entry screen provides you with a matrix including the alphabet as well as a "space" character and a symbol representing the backspace capability.

Use the joystick to select a letter in the matrix and press either **A** or **B** to add that letter to the name.

When you have finished entering the name, press **OPTION 2** to return to the Game Setup display.

If you elect to not enter a name for a color, human players names will default to "PLAYER" and the computer's name will default to "MASTER"

Color

Players' color may be changed using the color icon which is a **two-colored double ended arrow icon** lying between the player names.

Since **Silver always moves first**, you may wish to change colors before starting a game so that the computer makes the first move.

If, during a game, you decide that you would like to **changes sides** with the computer or your opponent, you may do so by using this icon.

You may also use this capability to **make the computer play against itself** by changing colors each time the computer completes a move.

To change player colors, position the pointer over the color icon and press either **A** or **B**.

Number of Players

The number of players is indicated by an icon in the form of one or two "3-D" style king pieces located at the left center of the display. One king indicates that the player is playing against the computer. Two kings indicates that both players are human.

You may change the number of players before beginning a game or at any time during a game. This allows you to **have the computer take over for a player** or vice-versa.

To change the number of players, position the pointer over the number of players icon and press either **A** or **B**.

Mode of Play

Mode of play controls the way in which the computer will behave if it is playing. This parameter has no effect if both players are human.

The mode of play is indicated by a textual description located near the center of the display. There are **three possible modes of play**:

- **Time**
- **Depth**
- **Infinite**

You may change the mode of play before beginning a game or at any time during a game.

To change the mode of play, position the pointer over the **Mode** text and press either **A** or **B**.

Time Mode

Time mode means that the computer is unrestricted in search depth (ply) when looking for it's next move, and that the move will be executed based on an average elapsed time. There are **eight levels of time mode** with **TIME 1** having the shortest average elapsed time per move, therefore being the easiest **TIME** level.

Depth Mode

Depth mode means that the computer is restricted in search depth to the number of ply specified when looking for it's next move, but is unrestricted in the time it takes to fully search that ply level. This means that the computer will not execute a move until it has finished it's search at the specified depth.

There are **eight levels of depth mode** with DEPTH: 1 searching only 1 ply, and DEPTH 8 searching to 8 plies. DEPTH 1 is the easiest of the DEPTH modes.

Infinite Mode

Infinite mode means that the computer is unrestricted in both search depth and time. In this mode, the computer will try to completely solve the game on each move.

Level of Play

Level of play further qualifies the Mode of Play selected. As in the Mode of Play, this parameter has no effect if both players are human.

For a description of how the level applies to the mode selected, see the Mode of Play section.

The level of play is indicated by a number displayed immediately to the right of the Mode of Play text. Since there is only one level of play in Infinite mode, no number is displayed in that mode.

You may change the level of play before beginning a game or at any time during a game.

To change the level of play, position the pointer over the Level number and press either **A** or **B**.

Display Mode

The Game Board can appear in either a three-dimensional "perspective view" mode, or a two dimensional "looking-down view" mode.

The Display Mode is indicated by an icon in the form of the game board as it appears in the selected mode. This icon is located at the right center of the display.

You may change the Display Mode before beginning a game or at any time during a game.

To change the Display Mode, position the pointer over the Display Mode icon and press either **A** or **B**.

You may also change the Display Mode during a game **without having to leave the Game Board** display. To do this, simply hold the **OPTION 1** and **OPTION 2** buttons down simultaneously. The display will change modes before your eyes.

Board Rotation

A two-player game session can be configured so that the board rotates 180 degrees after each move. This is especially desirable in the three-dimensional display mode where the player views the board with their home row closest to them.

By default, Board Rotation is enabled when the Game Board is configured for a three-dimensional view and is disabled when the Game Board is configured for a two-dimensional view.

Board Rotation is not available for one player games.

Board Rotation is represented by an icon in the form of two arrows located at the bottom left of the display.

You may enable or disable Board Rotation before beginning a game or at any time during a game.

To enable or disable Board Rotation, position the pointer over the Board Rotation icon and press either **A** or **B**.

Sound

Sounds can be enabled or disabled. Sounds are enabled by default.

Sound status is represented by an icon in the form of a speaker located to the right of the Board Rotation icon at the bottom of the display.

You may enable or disable Sound before beginning a game or at any time during a game.

To enable or disable Sound, position the pointer over the Board Rotation icon and press either **A** or **B**.

Move Timer

A timer displaying the elapsed time for the current move is displayed by default. This timer can be disabled.

Move Timer status is represented by an icon in the form of a clock located to the right of the Sound icon at the bottom of the display.

You may enable or disable the Move Timer before beginning a game or at any time during a game.

To enable or disable the Move Timer, position the pointer over the Move Timer icon and press either **A** or **B**.

Messages

During the course of a game session, Messages are displayed indicating important events like "Check" and "Checkmate". These Messages can be disabled.

Message status is represented by an icon in the form of a message box located at the bottom right of the Game Setup display.

You may enable or disable Messages before beginning a game or at any time during a game.

To enable or disable Messages, position the pointer over the Messages icon and press either **A** or **B**.

Exiting Game Setup

When you have completed your configuration of the current game session, you may exit to either the Game Board display or to the Statistics display.

Exiting the Game Setup display to the Game Board display will effectively start a new game session if no moves have been made in the current session, or resume the current session if a game is in progress. To do this, press the **OPTION 2** key.

To exit the Game Setup display to the Statistics display, press the **OPTION 1** key.

Game Board

The Game Board display shows the game board and pieces, and is the display where the game is actually played.

Move Entry

When the computer is waiting for a move to be entered either one of the board squares will be highlighted to a green color or an arrow will appear off the board. Move the joystick to see how you may change the position of the highlighted square or arrow. This mechanism gives you the ability to "point" at any location on the chess board.

Also when the computer is waiting for a move, the computer provides visual cues to indicate whose turn it currently is. On the three-dimensional board display, the move timer's color will match the color of the player's name whose turn it currently is. On the two-dimensional display, only the name of the player whose turn it currently is, and the move timer are displayed.

To begin entering a move, position the green square under the piece you wish to move and press 'A'. If you have initiated a valid move, the computer will make an acceptance sound. If you have attempted to initiate an invalid move, the computer will so indicate with a sound and message.

To complete the move, position the green square on the square to which you wish to move the selected piece and press 'A' again. Note that the square under the selected piece has remained green for easy reference. If you have completed a valid move, the computer will make an acceptance sound and move the selected piece as indicated. If you have attempted to move the selected piece incorrectly, you will be notified of an "invalid move" and will have to re-select the piece you wish to move.

Accidental Move Entry

If you have accidentally selected a piece which you do not wish to move, or if you wish to select another chess piece, **pressing 'B' while a piece is selected will cause that piece to be released.** Then you may begin move entry again by selecting another piece.

If you have finished entering a move and wish to withdraw it you may do so. In the case of a one player game, at the completion of your last move, the computer will have accepted your move and will be considering it's countermove. In this case, wait for the computer to complete it's move and then indicate that you wish to Take Back your move. Both the computer's last move and your last move will be withdrawn. In the case of a two player game, simply pressing Take Back before the other player begins their move will cause your move to be withdrawn. See the Take Back section for more information on this function.

Special Moves

En Passant

The computer will capture a pawn "en passant" whenever it determines that such a move is desirable, and it will also recognize when you choose to move "en passant".

Castling

The computer will castle whenever it determines that such a move is desirable, and it will also recognize when you choose to "castle". You may **castle by moving your King two squares toward the Rook**. The Rook will be moved automatically.

Promotion

As in a normal game of chess, when a pawn reaches the eighth rank, it may be promoted to a higher-valued piece, usually a queen.

Once you have moved a pawn to the eighth rank, a window will appear in the middle of the screen with a queen displayed within it. You may change the piece within the window by using the joystick. **Use the joystick to select which type of piece to which you wish to promote your pawn and press 'A'**. The promoted piece will then appear on the game board.

If one of the computer's pawns reaches the eighth rank, the computer will evaluate it's present position and will promote the pawn to the piece it feels will be of most value.

Check

Any time there is a check situation on the board, the computer will announce it with both sound and a message. Any time a mating move is entered, the computer will also announce this with both sound and a message.

Mate and Draw

The following sections discuss the ways in which a game may be concluded. Once the conclusion of a game has been announced, the game is over and cannot be continued. You may, however, view the Statistics display to assess your play and study your game.

Checkmate

Any time a mating move is entered, the computer will announce this with both sound and a message.

Draw by Stalemate

A game is drawn by stalemate if the player whose turn it is to move has no legal moves, but his king is not in check. The computer detects this draw and announces it as a stalemate with both sound and a message.

Draw by Fifty Move Rule

If fifty consecutive moves have been played in a game without either side having moved a pawn or captured a piece, a fifty move draw may be claimed by the side whose turn it is. The computer will detect this draw and announces it with both sound and a message.

Draw by Third Repetition

If the same position occurs three times in a game of chess where the same side has the move each time, the game is drawn by repetition of position. The computer will detect this draw and announces it with both sound and a message.

Take Back

The Take Back function allows you to take back any move you make or any move made by the computer. The computer will allow you to take back up to 200 half-moves (100 moves per player) in a single game.

To take back a move, press the 'A' and 'B' buttons simultaneously.

In the case of a one player game, both your last move and the computer's counter move will be withdrawn. In the case of a two player game, your move will be withdrawn.

The Take Back function is only available during a human player's turn.

Force Move

You may, at any time the computer is thinking, force it to stop considering it's next move and make it's best calculated move at that point.

To force the computer to move, hold the 'A' button down while the computer is thinking. It may take up to a second, but the computer will make a sound to indicate that it accepts the force request and will make it's move.

Hint

If it is your turn and you would like the computer to suggest a move, you make request a hint. The computer may or may not elect to provide one.

If the computer elects to suggest a move, it will indicate it's suggested move by making a sound and repeatedly flashing the "from" and "to" positions for the hint.

To obtain a hint from the computer, press 'B' while no move entry is in progress (no piece has been selected).

Hints are not available in two player games.

Board Display Mode

The Game Board can appear in either a three-dimensional "perspective view" mode, or a two dimensional "looking-down view" mode. You may change the Display Mode during a game without having to leave the Game Board display.

To change Board Display modes, simply hold the OPTION 1 and OPTION 2 buttons down simultaneously. It may take up to a second, but the display will change modes before your eyes.

Board Display mode can only be changed during a human player's turn.

Problem Setup

While this program does not have a direct problem setup capability, it is possible to setup and solve problems using combinations of the various configurations available.

You can set up a problem on the board by specifying a two player game and moving pieces from both sides to their desired position. You can then switch back to the Setup display and instruct the computer as to which color it should play from that point. Or, if you wish the computer to play both sides, you can both this with successive change color commands.

Exiting Game Board

At any point before, during or after a game, you may elect to leave the Game Board display to change the game configuration using the Game Setup display or to view game status using the Statistics display. This may be done without disturbing the status of the game in progress. However, **you cannot leave the Game Board display if the computer is thinking.**

To exit the Game Board display to the Statistics display, press the **OPTION 1** key.

To exit the Game Board display to the Game Setup display, press the **OPTION 2** key.

Statistics

The Statistics display is an informative display showing, in a columnar format, each player's name, total elapsed time, score and move history for the current game.

Scoring

A score is kept for each player throughout a game and is displayed below that player's elapsed game time.

A positive score indicates that the player currently enjoys an advantage while a negative score indicates that the player is at a disadvantage.

Scores are calculated based on the following piece values:

Pawn	100 points
Knight	300 points
Bishop	350 points
Rook	500 points
Queen	900 points

Move History

A history is kept of all moves made in the current game. Each player's move history is displayed in a scrollable column below that player's score. The number of a particular move is displayed in a column between the two players' move histories.

Moves are displayed using Standard or Coordinate notation. Each square on the chess board is designated, in accordance with international chess notation, by a letter of the alphabet designating the vertical columns (files) and a number designating the horizontal rows (ranks). Thus at the beginning of the game, the white king is on square E1 and the black king is on square E8.

You may scroll through the entire move history of the game by using the joystick to move the list up and down.

Exiting Statistics

When you have finished viewing the current game statistics, you may elect to leave the Statistics display to change the game configuration using the Game Setup display, or to resume the current game on the Game Board display.

To exit the Statistics display to the Game Board display, press the **OPTION 1** key.

To exit the Statistics display to the Game Setup display, press the **OPTION 2** key.

TELEGAMES' LIMITED 90-DAY WARRANTY

LYNX™ VIDEO GAME CARD

LIMITED 90-DAY WARRANTY: TELEGAMES, INCORPORATED ("Telegames") warrants to the original consumer purchaser that this Atari Lynx Video Game Card ("Media") is free from any defects in materials and workmanship for a period of ninety (90) days from date of purchase. If any defect covered by this warranty is discovered within that 90-day period, the unit should be returned to the place of purchase along with original proof-of-purchase. The place of purchase will either repair or replace the defective unit at their option.

Warranty service can only be carried out if proof-of-purchase is received with the product by Telegames during the ninety (90) day warranty period and the product has been carefully packaged by you to avoid transit damage.

This warranty does not cover damage or malfunctions resulting from improper handling, accident, misuse, abuse, failure of electrical power, use with other products not manufactured or approved by Atari for use with the Lynx Video Game System, damage while in transit for repairs, repairs attempted by any unauthorized person or agency, or any other reason not due to defects in materials or workmanship.

DISCLAIMER OF WARRANTY ON TELEGAMES

LYNX PROGRAMS: All Telegames Lynx programs (contained within the Media) and related informational materials are distributed on an "as is" basis without warranty of any kind. Any statements concerning the capabilities or utility of a Lynx program are not to be construed as express or implied warranties. The entire risk as to the quality and performance of such Lynx programs is with the purchaser. Should a program fail to fulfill the individual requirements of the purchaser or prove defective following its purchase, the purchaser (and not the manufacturer, distributor, or retailer) assumes the entire cost of all servicing, damages or liabilities which may result from the use of reliance of any such Lynx program and/or related informational materials.

Telegames shall have no liability or responsibility to the purchaser, or any other person or entity with respect to any loss or damage caused or alleged to be caused directly or indirectly by any game or computer program (on any media) sold by Telegames or others. This includes, but is not limited to, any interruption of service, loss of business, loss of information or that which is rendered inaccurate, or loss of anticipated profits or ANY OTHER CONSEQUENTIAL OR INCIDENTAL DAMAGES RESULTING FROM THE PURCHASE, USE OR OPERATION OF TELEGAMES LYNX PROGRAMS.

Every effort has been made to ensure that the Telegames product manual and promotional materials accurately document the product. However, because of on-going improvements and updating of Telegames products, Telegames cannot guarantee the accuracy of printed material after the date of publication and disclaims liability for changes, errors or omissions.

Telegames shall have no obligation to enhance or update ANY UNIT once manufactured.

WARRANTY LIMITATIONS: ANY APPLICABLE IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS, ARE HEREBY LIMITED TO NINETY DAYS FROM THE DATE OF PURCHASE, AND CONSEQUENTIAL OR INCIDENTAL DAMAGES RESULTING FROM A BREACH OF ANY APPLICABLE EXPRESS OR IMPLIED WARRANTIES ARE HEREBY EXCLUDED.

Since some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusions or limitations of incidental or consequential damages, the above limitations or exclusions may not apply to you. This warranty gives you very specific legal rights and you may also have other rights which vary from state to state.

If your retailer is unable to provide the warranty repair service you require, you may contact Telegames, Incorporated as follows:

**TELEGAMES CUSTOMER RELATIONS
POST OFFICE BOX 901
LANCASTER, TX 75146
OR
TELEGAMES CUSTOMER RELATIONS
KILBY BRIDGE, WIGSTON
LEICESTER, LE18 3TE, ENGLAND**

**FOR INFORMATION ON
OTHER TELEGAMES
PRODUCTS, FOLLOW THESE
EASY STEPS:**

1. Complete the information on this certificate,
and
2. Mail it to:

**TELEGAMES CUSTOMER SERVICE
BOX 901 LANCASTER, TX 75146 U.S.A.**

OR

**TELEGAMES CUSTOMER SERVICE
KILBY BRIDGE, WIGSTON
LEICESTER, LE18 3TE, ENGLAND**

Name _____

Address _____

City _____

State _____ Zip _____

Telephone () _____

Country _____

Copyright 1991, Telegames Inc.
Lancaster, Texas 75146
All rights reserved.